

Supplied Components

- 1 Roll Bar, high-grade steel
- 2 Side Mounting Plates, high-grade steel
- 2 Spacer sleeves, high-grade steel
- 2 Screws M10x 30, high-grade steel
- 2 Self-locking nuts/washers M10, galvanized
- 2 Countersunk screws M12x 30, galvanized

Tools Needed

- Allen key 8mm
- Thin spanners 13mm, 17mm
- Drill, 12mm bit

Disassembly of the seat belt towers

- Open roof
- Remove plastic caps from upper seat belt towers.
- Loosen and remove seat belt retaining screws (1).
- Remove spacer sleeves under belt towers.

Drill the 2 mounting plates

- Install the side mounting plates using the spacer sleeves with the belt retaining screws.
- Mark holes by the side parts (2)
- Drill the holes (12mm diameter)

Assembly of the roll bar

- Align the mounting plates with the roll bar holes (11mm) and bolt and torque the side mounting plates with the countersunk screws M12x30 to 38Nm.
- Install the M10x30 screws (3) through mounting plates, side part and body with nuts/washers M10 bolts. (see wearing parts position).
- Install spacer sleeves in side parts.
- Bolt belt retaining screws into spacer sleeves (torque 38 -72 Nm)
- Re install plastic caps.



Scimitar International Ltd.
Unit 4, Cluster Industrial Estate
Rodney Road, Portsmouth
Hampshire, PO4 8ST
Tel: 0845 345 2384 **Fax:** 0845 345 2385
Website: <http://www.mx5parts.co.uk>

© Copyright 2002, Scimitar International Ltd.

These fitting instructions are supplied in good faith, and as a guide only. We accept no responsibility or liability for any damages, injury or loss caused as a result of following these instructions. Your statutory rights are not affected.